

# HP Laptop - Wifi - How to install rtl8723de driver on Ubuntu 18.04 18.10 or earlier:

```
sudo apt-get install git dkms libelf-dev
```

```
git clone https://github.com/vvmospace/rtl8723de.git
```

```
sudo dkms add ./rtl8723de
```

```
sudo dkms install rtl8723de/5.1.1.8_21285.20171026_COEX20170111-1414
```

```
sudo reboot
```